



IMPORTANT

Use the Correct Brake Pads

Customers must use Williams Carbon Brake Pads. Use of any other brake pads with these wheels will void the warranty.

Modulate Braking

Excessive braking on long descents can cause overheating that could damage the rim and braking surface. This is most likely to occur during long periods of continuous, hard braking. To avoid overheating damage, modulate your braking by feathering the brakes (compressing then releasing) or alternating between front and rear brakes. Briefly releasing one or both of the brakes allows the rim temperature to drop and prevents overheating damage.